

Cleaning and Maintenance

Care and Maintenance

Always power the film off when cleaning and do not power on until 100% dry. Be careful not to disturb any electrical connections.

The *only* warranty approved cleaner is *Smart Tint® Cleaner* and a lint free micro fiber/nanofiber cloth. Our poly vinyl surface is durable and scratch resistant however it is recommended to avoid harsh paper towels. As they would create light scratches and hazing over time. You may squeegee with a rubber squeegee only using our cleaner for high elevation windows. *Do not use any abrasive cleaners, industrial strength glass cleaners and/or any other traditional glass cleaners or window cleaning tools that may scratch the window film*. Please note that traditional glass cleaners are not designed to clean and maintain window films as the chemicals in them will derogate and deteriorate window film performance. Remember smart films are scratch resistant not scratch proof.

Available At:



SmartTintCleaner.com





Lowes.com